



NAUTICAL- HGM SERIES (Whirling hygrometer)

Applications:

Two thermometers are placed in flowing air. One thermometer bulb being covered by a wet wick. Evaporation from the wetted bulb causes its temperature to be depressed relative to that of the dry bulb. A handle enables the instruments to be whirled. The % RH can be read off the slide rule calculator integrated into the psychrometer

Specifications:

Range: -5 + 50 Deg. C&F (ZEAL P2501), 0-45 Deg. C&F (WD-2)



** Non-standard specifications from above can be customize on indent basis.

*** All information subject to changes without prior notice owing to continuous development